

# SCHUMANN DEVICES

## EARTHSAFE Pocket

The only TUNABLE Schumann Device



We all know that our bodies are very delicate electromagnetic senders and receivers. And each of us is different (even unique) in the ways in which our bodies interact with the electromagnetic environment. By creating a Schumann device

with a variable capacitor, the EarthSafe has the unique ability to be tuned from about 2 Hz to over 20 Hz, to produce the exact frequency that will give maximum benefit to your specific body. And it can be re-adjusted in seconds at any time, for any new circumstance, including the changes taking place in the Earth's natural field. You may notice a difference immediately. Some people have said that it feels as though an invisible weight has been lifted off their shoulders. Irritability, eye strain, and general tiredness from using electrical appliances can feel lessened. Pocket sized (5 1/4" x 2 3/4" x 1"), lightweight (only 6 oz.), it goes with you wherever you go. Tuning is easily done with simple muscle testing. Tune up your protective energy field with EarthSafe. 9v battery included, made in USA.

**Earthsafe Pocket (Cat. #D380) .. \$169.99**

## EARTHSAFE TUNING DEVICE

### "PHOTO TACHOMETER"

Simple Way To Measure the Frequency of EarthSafe

The EarthSafe has an LED which blinks at the same frequency set on the device. This Photo Tachometer can read the blinking LED and tell you the frequency with great precision. Allows repeated setting and re-setting of the EarthSafe to any frequency within its range. Just point the Photo Tachometer at the blinking LED and see the reading. Useful up to about 5 inches from the LED. **Readout is in RPM (which is cycles per minute) so simply divide by 60 to get Hz (cycles per second).** 7.83 Hz = 469.8 RPM. Can also be used to measure the frequency of moving (rotating or oscillating) objects. Nice carry case included. 5 digit LCD display. *EarthSafe sold separately.*




Range: 5-99,999 RPM  
Accuracy: ±(0.05% + 1 digit)  
Batteries: 4x AA (not included)

**Photo Tachometer (Cat. #D382) .. \$39.95**

## EARTHSAFE Whole House

Table Top Unit.

Stronger than Pocket Version.



Same tunable Schumann circuitry, but more powerful to cover a larger area. Some say it adds sound depth to high end audio equipment. Includes optional ground cord to inject the signal into the wiring of your building. 12V adapter plugs into AC outlet so no batteries to wear out. North American adapter supplied.

**(Cat. #D381) ..... \$249.95**

## Universal International 12V DC Power Supply

Light weight, compact and efficient



switch mode

design incorporates highly regulated output within ± 0.25V of rated output, even with no load. Input: 100V~240V and 50~60Hz so it works anywhere in the world. Output: 12VDC. 5' output cord with 5.5mm x 2.1mm center positive coaxial DC power plug. North American plug, can be used with an international plug converter, see page 32. **(Cat. #D174-A) ..... \$8.95**

## Prefer to hear the signal from your EarthSafe?

**eSmog Scout** converts the electromagnetic signal from the EarthSafe into a corresponding frequency that you can actually hear. Just turn it on and hold it close to the EarthSafe (about 3"). You will hear a distinct clicking sound which varies in frequency as you tune the EarthSafe. Very easy to use. eSmog Scout will also pick up other electromagnetic signals, so be sure to find an electromagnetically "quiet" zone to check your EarthSafe. LED readout has nothing to do with this function. **eSmog Scout (Cat. #D101) \$49.95**



Toll free in USA: 1-888-537-7363  
International: +1-518-432-1550

Fax: 1-309-422-4355  
www.lessemf.com